

Version 1.4(2023.03.22)

WWW.CONOTEC.CO.KR

CONOTEC

CONOTEC CO., LTD.


DIGITAL TEMPERATURE CONTROLLER



ISO 9001:2008

CNT-P100

Instruction Manual



- ◆ PID temperature controller
- ◆ Relay/SSR PID,Current PID control
- ◆ RS485(MODBUS)support
- ◆ NTC10K/CA(K)/PT100 sensor selectable
- ◆ 3 kinds of sensor mounted by auto tuning only once

※ CNT-P100 is a controller that can perform PID function for PID, SSR PID, 4 ~ 20mA current and can select a sensor from menu among three types of NTC10K / PT100 / CA (K).

- A user manual for this product is posted on the company website.
- Please download the technical document and communications manual on the company website

## 01 Safety precautions

Please read the safety precautions carefully for correct operation of the product.

※ The specifications and dimensions specified in this instruction manual may be changed without any notice for performance enhancement.

### ▲ Warning

1. This product was not made as a safe device. Therefore, this product should be attached with dual safety devices if it is used for the control purposes (e.g. a device vulnerable to accident and property damage, etc.).
2. Do not wire, inspect or service this product while the power is being supplied.
3. You must attach this product to a panel. Otherwise, it may cause an electric shock.
4. When connecting the power, you must check the terminal number.
5. Do not ever disassemble, process, modify or repair this product.

### ▲ Caution

1. Please make yourself familiar with all the operation instructions, safety precautions and warnings before using this product. Comply with related specifications and capacity requirements
2. Do not wire or install this product to any unit with high inductive load (e.g. motor, solenoid, etc.).
3. Use a shielded cable with a proper length when extending a sensor.
4. Do not use any part that generates an arc when used in the same power or directly switched in close proximity.
5. Keep the power cable away from a high-voltage cable and do not install this product in any place that is full of water, oil and dust.
6. Do not install this product in any place that is exposed to direct sunlight or rain.
7. Do not install this product in any place that is subject to strong magnetic power, noise, vibration or shock.

8. Keep this product away from any place that generates strong alkaline or acid substances. Use a separate pipe.
9. Do not sprinkle water onto this product for cleaning when installing it in the kitchen.
10. Do not install this product in any place where the temperature/humidity ratings are exceeded
11. The sensor cable should not be cut or cracked..
12. Keep the sensor cable away from a signal cable, a power cable or a load cable. Use a separate pipe.
13. Keep in mind that the follow-up service will not be available if this product has been arbitrarily disassembled and modified
14. ⚠ symbol on the terminal wiring diagram indicates a safety statement that alerts a warning or caution.
15. Do not use this product near any device generating strong high-frequency noise (e.g. high-frequency welding machine high-frequency sewing machine, high-frequency radio, large-capacity SCR controller, etc.).
16. Using this product in any method other than those specified by the manufacturer may lead an injury or a property damage
17. The product is not a toy. Keep it away from children.
18. The product should be installed only by an expert or a qualified person.
19. The company will not be liable for any damage caused by the violation of the above warnings and cautions or by a consumer's fault

### ▲ Danger

Caution: Risk of electric shock

- Electric shock – Do not touch the AC terminal while the current is flowing. It may cause an electric shock.
- You must disconnect the input power when servicing it.

## 02 Main features

- \* PT100, CA(K), NTC10K — 3 kinds of sensor selectable
- \* Control of relay PID, SSR PID, current PID \* RS485 MODUB RTU available
- \* Function to transfer 4 ~ 20mA PV
- \* Uncomplicated entry-level PID controller

## 03 Specifications


Input power	24~48VDC	Consumption power	
Display	7segment 3.5Digit 0.51Inch	Weight	
Sensor type	PT100, CA(K), NTC10K		
Display accuracy	PT100, NTC10K : ±1% rdg ± 1 digit CA(K) : ±1% rdg ± 1 digit		
Output specifications	Out1(relay) : ON/OFF output or alarm output or PID control (250Vac 2A Max, 1a relay) Out2(SSR / current) : SSR PID or current PID or PV transmit (Current:resistive load within 500ohm, SSR 11VDC±2V within 20mA)		
Communication specifications	RS485, Modbus RTU, Data 8bit / ParityNone / Stop 1		
Proportional band width(P)	PT100,NTC10K : 0~100.0℃ CA(K) : 0~100℃	integral time(I)	0~1999sec
Normal state error correction	PT100,NTC10K : -100.0~100.0℃ CA(K) : -100~100℃	derivative time(D)	0~1999sec
Ambient	0~55℃, 35~80%Rh(no freezing or dew condensation)	control cycle(T)	0~120sec
		Memory term	about 10 years(non-volatile)

## 04 Model Types


Model	Sensor	Output	Communication	Input power
CNT-P100	NTC10K/PT100/CA(K)	Relay 1 SSR / Current 1	RS485 Modbus RTU	48VDC / 24~48VDC

NTC10K 3M is included as standard but,(PT100,CA(K)) sensor not included.


## 05 Components



## 06 Terminal wiring diagram



## 07 Diemension and panel hole sizes



## 08 Setting process

How to change the set temperature

Auto-tuning start/stop

Initialize the set value

Program setting (The value of each item is the factory setting.)

1 Menu settings cannot be changed during auto-tuning  
**SEE In du1 Pb ti td rSt A.H A.Lo tYP**  
To change your settings, press **▲+▼** keys simultaneously to turn off auto tuning before change.  
When you try to change the value of the top menu during auto-tuning, **tYP** letters appears briefly.

2 **In** sensor selection  
**Pt** RTD PT100 ohm, -199 ~ 400 ℃  
**CAK** K thermocouple sensor, -50 ~ 1200 ℃  
**ntC** NTC10Kohm CONOTEC model no. FS-200N), -55.0~99.9 ℃  
Menu below is stored in a separate memory space according to the sensor type, and **Pb ti td** is automatically saved to suit different sensors with one sensor tuning. In other words, changing the sensor after the completion of auto-tuning does not require re-tuning.  
**SEt Cor Pb ti td rSt HP- LP- t.20 t.4**  
However, if you want a precise auto-tuning to fit the sensor, you may do re-tuning after selecting the desired sensor.

3 **du1** OUT1 selection  
⚠ Note: OUT2 output is selected automatically by selecting OUT1 output.

OUT1 : Relay output	OUT2 : SSR or 전류출력
<b>r.Pd</b> Alarm output	<b>A.Pd</b> 4~20mA current PID control
<b>r.A1</b>	<b>S.Pd</b> SSR PID control
<b>r.Pd</b> Relay PID control	<b>A.Pb</b> 4~20mA current PV transment
<b>r.nF</b> Relay On/OFF control	

4 **Cor** Sensor correction

When there is a difference between the present temperature displayed and the temperature measured by precision instruments, you may match the displayed value to the actual measured temperature.  
Example 1) Display Value: 5 degrees, the actual measured temperature: 10 degrees => input **Cor** +5 degree  
Example 2) Display Value: 5 degrees, the actual measured temperature: 2 degrees => input **Cor** -3 degree

5 **Adr** RS485 communication address

It is a menu to align an address with upper system for RS485 communication.  
Example) If the F-P100 address of the PC program is set to 3, the **Adr** menu should meet 3.

6 **bps** RS485 communicaton speed

This is a menu to align communication speed to match an upper system for RS485 communication.  
Example) If the communication speed of the PC program is at 9600**bps**, **bps** menu should meet 960.  
**120** : 1200 **bps**, **240** : 2400 **bps**, **480** : 4800 **bps**,  
**960** : 9600 **bps**, **192** : 19200 **bps**

7 **CPl** Control cycle

When implementing **Pd** control / **P** control / **Pl** control, etc. using a relay or **SSr** output, ON and Off are repeated within a set time cycle, which is called as a control cycle.  
⚠ Note: When performing **Pd** control by relay, if the control cycle is too short, life of the relay contact may be shorten with frequent ON/OFF.

8 **Pb** Proportional Band

If current temperature is within proportional band width, control by adjusting the rate of ON/OFF in **CPl**.

9 **ti** Integration time


Integration time means the time for obtaining the same manipulated variable with proportional operation with only integral action. Proportional operation alone cannot reach the target temp., and temperature deviation occurs. Integral action ensures that the current temperature reaches the target temperature adding integrated deviation.  
\* If the integral time is too short: regular vibrations may occur.  
\* If the integration time is too long: difficut to reach the target temperature or takes long time.  
\* If integral time is 0, integral action does not work.

10 **t<sub>d</sub>** Time proportional integral derivative time

Derivative time is the time from when the deviation is proportional action only get the amount of operation such as differential behavior when changing constantly. D action by monitoring a variation of the disturbance takes place rapidly, when the difference between the previous deviation of the operation amount is large, added much to quickly respond to the disturbance.  
\* If the derivative time is too short: late response to disturbance.  
\* If the derivative time is too long: regular vibration may occur.  
\* If the differential time is 0, no derivative action.

11 **r<sub>St</sub>** Correction of deviation in a steady-state

Applicable when using (P) action only. (P) action alone cannot reach target temperature ans will have a steady-state deviation. Deviation can be corrected using **r<sub>St</sub>** menu.



12 **R<sub>H</sub>** Maximum output of current control

Current output value of 100% operation when operating **P<sub>i</sub>d** control with current output.  
Ex) **R<sub>H</sub>** = 15.0mA is the curen<sup>t</sup> output value at , 100% operation, current output 15.0mA

13 **R<sub>Lo</sub>** Current control output minimum value


This will be the current output value if the manipulated variable is 0% and it's the case of operation such as **P<sub>i</sub>d** control etc., as the current output  
Ex) **R<sub>Lo</sub>** = 10.0mA If the current output of 10.0mA when the manipulated variable of 0%

14 **t<sub>YP</sub>** Output type

Heater : **t<sub>HE</sub>** setting Cooler : **t<sub>Co</sub>** setting


15 **d<sub>i</sub>F** Output deviation temperature setting

\* Direction of deviation: one direction (+ direction). \* Output OFF at setpoint  
When the relay output is repeated too frequent ON / OFF, output contacts are quickly damaged or hunting by external noise (oscillation, chattering) occurs.It is a function to protect contact of the device by setting a regular intervals between ON and OFF to avoid such phenomina.



16 **d<sub>LE</sub>** Set Output Delay Time

If a problem occurs frequently repeating ON/OFF operation, it functions to protect the device from momentary power failure or power resumption (chillers, compressors, etc.)




17 **R<sub>LS</sub>** Alarm output type setting

**HP<sub>r</sub>** Alarm output high limit temperature setting

**R<sub>Lo</sub>** : Alarm output type when out of the range  
alarming when displayed temperature is out of the range




**R<sub>Li</sub>** : Alarm output type when within the range  
alarming when displayed temperature is within the range



18 **t<sub>20</sub>** Temperature setting that corresponds to 20mA current output in PV transmission output.

**t<sub>4</sub>** Temperature setting that corresponds to 4mA current output in PV transmission output.

To send the present temperature to the current output, by dividing the set temperature range at **t<sub>20</sub>** and **t<sub>4</sub>** and output as 4~20mA.  
Output a current corresponding to the temperature change by 0.1 degrees.




09 Control output

1 Relay ON/OFF Control

If set **d<sub>U1</sub>** as **r<sub>oF</sub>**, OUT1:relay on/off output  
OUT2:4~20mA to be set as current output  
Refer and set **t<sub>YP</sub>** output type, **d<sub>i</sub>F** output deviation, temperature **d<sub>LE</sub>** output delay time, etc.,

2 P control : Perform P control when both integral time (t<sub>I</sub>) and differential time (t<sub>d</sub>) are zero

Output type	Setting & using terminal number
Relay P control	Set as <b>d<sub>U1</sub></b> as <b>r<sub>oF</sub></b> using terminal No. 7, 8 OUT1:relay P control, OUT2:P transmit ouput
55- P control	Set as <b>d<sub>U1</sub></b> as <b>r<sub>oF</sub></b> using terminal No. 9, 10 OUT1:alarm output, OUT2:55- P control
Current P control	Set as <b>d<sub>U1</sub></b> as <b>r<sub>oF</sub></b> using terminal No. 9, 10 OUT1:alarm output, OUT2:Current P control



P control alone cannot have the current temperature reach the set temperature and leaves residual variance. This is called steady-state error, which can be corrected using the **r<sub>St</sub>** (steady-state error compensation) menu.


3 P<sub>i</sub>d Control

Output type	Setting and using terminal number
Relay P <sub>i</sub> d control	<b>d<sub>U1</sub></b> :set as <b>r<sub>oF</sub></b> terminal using no. 7, 8 OUT1:relay P <sub>i</sub> d control, OUT2:P <sub>i</sub> d transmit
55- P <sub>i</sub> d control	<b>d<sub>U1</sub></b> :set as <b>r<sub>oF</sub></b> terminal using no. 9, 10 OUT1:alarm output, OUT2:55- P <sub>i</sub> d control
Curren P <sub>i</sub> d control	<b>d<sub>U1</sub></b> :set as <b>r<sub>oF</sub></b> terminal using no. 9, 10 OUT1:alarm output, OUT2:current P <sub>i</sub> d contro

P<sub>i</sub>d control calculates optimum coefficient through the auto -tuning and allows you to effectively maintain the target temperature.


-Auto tuning

After two or three times on and off in the vicinity of the set temperature, complete tuning. Even if the sensor is changed,it is not necessary to re-tune existing one.




- \* Relay P<sub>i</sub>d and 55- P<sub>i</sub>d control operate in the format of dividing control cycle into on and off section as a percentage.
- \* Minimum on and off times in case of Relay PID control:  
when **t<sub>PE</sub>** is less than 5 seconds: 0.3 seconds  
less than 10 seconds: 0.5 second  
more than 10 seconds: 1 second
- \* Minimum on and off time at 55- P<sub>i</sub>d control is 0.05 seconds unconditionally(50mS).

△ Note: When performing P<sub>i</sub>d control by relay, if the control cycle is too short, life of the relay contact may be shorten with frequent ON/OFF



-55- output

\* 55- output is OnOff type output same as relay output and the ratio of On and Off varies depending on the controlled variable.




\* 55- output may use No. 9 & 10 current output terminal.

10 Communication output


- \* RS485 MODBUS RTU type of protocol is built-in.
- \* 2-wire half-duplex asynchronous communication system \* Working distance: within 1.2Km
- \* Communication speed : 1200 / 2400 / 4800 / 9600 / 19200BPS
- \* Start bit: 1bit, stop bit : 1bit, parity bit : None, data bit : 8bit

1 Modbus Mapping Table

[ Func 0x02 : Read Discrete Inputs ] You can receive a brief information in the form of bits, such as a sensor status and a decimal.




[ Func 0x04 : Read Input Registers ] You can receive brief information such as Commands, Start address, Number of data, Temperature, Decimal, Current temperature, status of the sensor and decimal.




NO	Address	Description	Range	Unit	Value at shipment
300001	0000	present temperature	at a sensor error : -5000	℃	
300002	0001	Sensor information	0:PT100, 1:CA(K), 2:NTC10K		
		sensor open error	bit0 0:no error, 1:open error		
		sensor short error	bit1 0:no error, 1:short error		
		internal sensor error	bit2 0:no error, 1:sensor error		
		temperature decimal point	bit3 0:none, 1:has a decimal point		
300003	0002				
		output setting status	bit0 00 - Out1 : On/Off Output, Out2 : P <sub>i</sub> Transmission Output 01 - Out1 : Relay/Pid Output, Out2 : P <sub>i</sub> Transmission Output 10 - Out1 : Alarm Output, Out2 : 55- P <sub>i</sub> d Output 11 - Out1 : Alarm output, Out2 : Current P <sub>i</sub> d output		
		OUT1output state display	bit2 0:OFF, 1:ON		
		auto tuning check	bit3 0:tuningX, 1:on tuning		
300005	0004	PV transmit output current amount	4.0mA ~ 20.0mA		
300006	0005	PIDcontrol input	0.0 ~ 100.0%	%	
300007	0006	model no.(P100)	'P' '1'		0x5031
300008	0007	model no.(P100)	'0' '0'		0x3030
300009	0008	model no.(P100)			0x0000


[ Func 0x03 : Read Input Registers ] Able to read the set value



[ Func 0x06 : Write Single Register ] You can change the setting one by one.



[ Func 0x10 : Write Multiple Registers ] Several items of the setting values can be changed at a time. When writing multiple registers, if any of the data has errors, all of them will not be written. Use Func 0x06, as the Func 0x10 command is not available during autotuning.



[ MAP ]Func 0x03, 0x06, 0x10

NO	Address	Menu	Description	Range	Unit	Value at shipment
400001	0000	t <sub>n</sub>	Sensor selection	0:PT100, 1:CA(K), 2:NTC10K		2:NTC10K
			0 - Out1 : on/off, Out2 : PV transmit 1 - Out1 : RelayPid, Out2 : PV 2 - Out1 : Alarm, Out2 : SSR PID 3 - Out1 : Alarm, Out2 : 전류 PID			0 : - Out1 : On/Off output - Out2 : PV trasler output
400002	0001	o <sub>LE</sub>	Output type			
400003	0002	SEt	setting temperature	PT100 : -200 ~ 400℃ CA(K) : -50 ~ 1200℃ NTC10K : -55.0 ~ 99.9℃	℃	PT100 : 30.0℃ CA(K) : 30℃ NTC10K : 30.0℃
400004	0003	Co <sub>r</sub>	sensor correction of error	PT100 / NTC10K : -19.9 ~ 19.9℃ CA(K) : -19 ~ 19℃	℃	PT100 / NTC10K: 0.0℃ CA(K) : 0℃
400005	0004	R <sub>d</sub>	RS485address	1 ~ 99		1

NO	Address	Menu	Description	Range	Unit	Value at shipment
400006	0005	b <sub>PS</sub>	RS485speed	1200 / 2400 / 4800 / 9600 / 19200	BPS	9600
400007	0006	C <sub>PE</sub>	control cycle	1 ~ 120	sec	20
400008	0007	P <sub>b</sub>	proportional	PT100 / NTC10K : 0 ~ 100.0℃ CA(K) : 0 ~ 100℃	℃	PT100 / NTC10K:10.0 CA(K) : 10
400009	0008	t <sub>I</sub>	ntegral time	0 ~ 1999	sec	0
400010	0009	t <sub>d</sub>	derivative time	0 ~ 1999	sec	0
400011	000A	r <sub>St</sub>	steady-state error correction	PT100 / NTC10K : -100.0 ~ 100.0℃ CA(K) : -100 ~ 100℃	℃	PT100 / NTC10K:0.0℃ CA(K) : 0℃
400012	000B	R <sub>H</sub>	controlled current max. value	A.LO ~ 20mA	mA	20.0
400013	000C	R <sub>Lo</sub>	controlled current min. value	0.0mA ~ A.HI	mA	4.0
400014	000D	t <sub>YP</sub>	forward/backward output	0: heater control(forward) 1: cooling control(backward)		0: heater control (forward)
400015	000E	d <sub>i</sub> F	output deviation temperature	PT100 / NTC10K : 0.1 ~ 19.9℃ CA(K) : 1 ~ 19℃	℃	PT100 / NTC10K:0.1 CA(K) : 1
400016	000F	d <sub>LE</sub>	output delay time	0 ~ 1999	sec	0

400017	0010	R <sub>LS</sub>	alarm output type	0 : AL0 / 1 : AL1		0 : AL0
400018	0011	R <sub>dF</sub>	alarm output deviation	PT100 / NTC10K: 0.1 ~ 19.9℃ CA(K) : 1 ~ 19℃	℃	PT100 / NTC10K:0.1 CA(K) : 1
400019	0012	HP <sub>r</sub>	alarm output high limit	PT100 : LPR ~ 400℃ CA(K) : LPR ~ 1200℃ NTC10K : LPR ~ 99.9℃	℃	PT100 : 400℃ CA(K) : 1200℃ NTC10K : 99.9℃
400020	0013	LP <sub>r</sub>	alarm output low limit	PT100 : -200℃ ~ LPR CA(K) : -50℃ ~ LPR NTC10K : -55.0℃ ~ LPR	℃	PT100 : -200℃ CA(K) : -50℃ NTC10K : -55.0℃
400021	0014	t <sub>20</sub>	PV trasmit 20mA temperature	PT100 : T.4 ~ 400℃ CA(K) : T.4 ~ 1200℃ NTC10K : T.4 ~ 99.9℃	℃	PT100 : 400℃ CA(K) : 1200℃ NTC10K : 99.9℃
400022	0015	t <sub>4</sub>	PV trasmit 4mA temperature	PT100 : -200℃ ~ T.20 CA(K) : -50℃ ~ T.20 NTC10K : -55.0℃ ~ T.20	℃	PT100 : -200℃ CA(K) : -50℃ NTC10K : -55.0℃
400023	0016		auto-tuning control	0 : tuning completed, 1 : tuning start		0

[Exception Response] In the product whose sensor error is compensated, a command that is not supported, or when there are other errors, it returns the error information.

Sub products address	command	Error code	CRC16	Error Code
		low byte	high byte	0x01 : Command that does not support 0x02 : Start address error 0x03 : Error of the number of Data 0x04 : Abnormal processing of requested command
1BYTE	receiving command + 0x80	1BYTE	1BYTE	

11 Others

- \* Sensor extension  
- PT100 ohm Sensor: All 3 lines should have the same material and thickness.  
- CA(K) : CA(K) should be extended to the sensor wire or compensating cable only.  
- NTC10K : should extend using 2P shielded cable.  
=> Soldering is recommended for the extended area. Poor extension areas may cause a malfunction of the sensor due to inflow of moisture, etc.  
Be cautious.
- \* Sensor error display  
o<sub>LE</sub> : If the sensor cable has been either cut in the middle, loosen the terminal connection.  
5-E : When the sensor wires make short each other.  
i<sub>LE</sub> : When the temperature sensor for compensation of the cold junction inside the product is in malfunction.
- \* Memory error display  
Er<sub>i</sub> : in case an abnormal data is recorded in the non-volatile memory inside the product or damaged due to severe external noise.  
These settings will be changed to the factory default if you press the Set key when this mark ER1 appears.

\* The above specifications may be changed without any notice for performance enhancement. Please make yourself fully familiar with and follow the above precautions.

■ Warranty period: One year from the date of purchase

■ Address : (Street address) 56, Ballyongsandan 1-rp, Jangan-eup, Gijang-gun, Busan, ROK  
(Land-lot address) 901-1, Ballyong-ri, Jangan-eup, Gijang-gun, Busan, ROK (46034)

• Product service : 070-7815-8289  
• Customer service : 051-819-0425 ~ 0427  
• FAX : 051-819-4562  
• Email : overseas-sales@conotec.co.kr  
• SNS : Facebook, Instagram, Twitter, YouTube▶ 'Search for 'Conotec'  
• Website : www.conotec.co.kr

\* This manual was prepared in the Naver Nanum fonts.